


# Pro-160 / 360



SW1 & SW2 are DPDT key switches, only one to be active at any time.

Reverse 1 & 2 are not required if joystick operation is used.